

MICROLITER GLARE SHIELD INSTALLATION INSTRUCTIONS

MIC-GS

1. Back out and remove the door frame screws that hold the door to the fixture. Save these screws which will be used later.
2. Place the glare shield up against the door frame and align the holes in the glare shield with the holes in the door frame.
3. Insert the door frame screws through the glare shield then through the door frame assembly.
4. Close the door frame/glare shield combination against the fixture and secure in place by tightening the door frame screws.
5. Install the J-clip to the outside of the glare shield with the J portion pointing down and facing inward. Use the hole in lower section of the glare shield and attach with screw provided.
6. Loosen the screw and slide the J-clip down so that it can slip over the edge of the door frame. Slide the J-clip upward to obtain a good grip on the edge of the door frame.
7. Lock the J-clip in place by tightening the screw. This will make sure the lower portion of the glare shield fits tightly against the door frame.



© Hubbell/Lighting Division
2000 Electric Way
Christlansburg, Virginia 24073-2500
(703) 382-6111 FAX: (703) 382-1526

268-0484-9907